


Spare Parts

Repair Kit ST-2700

Item-No. 20 2700 490



Pos.	Item-No.	Description
1	20 2700 455	Valve ST-2700
1.1	01 0007 347	Set screw
1.2	06 0002 055	Pressure spring
1.3	04 0000 330	Stainless steel ball
1.4	04 0007 033	Valve seat
1.5	05 0001 521	O-ring ø10
1.6	05 0002 130	Back ring G10
2	04 0007 055	Piston rod
3	05 0000 260	O-ring ø3
4	05 0000 640	Back ring U3

Pos.	Item-No.	Description
5	02 0001 035	Assembling tool A
6	02 0001 038	Extension tool A
7	02 0001 036	Assembling tool C
8	02 0001 037	Assembling tool D
9	04 0001 006	Screw M4x60
10	00 0000 732	Instruction repair kit

Pos. 5 up to Pos. 10 are not shown.