


Spare Parts
Float valve ST 8
Item-No. 20 0008 . . .



Pos.	Item-No.	Description
1	01 0003 386	Housing 3/8" female
	01 0003 385	Housing 1/2" female
* 2	02 0000 600	Packing
* 3	02 0001 060	Sealingring
* 4	02 0000 585	Plunger
5	01 0000 510	Brass float arm
6	02 0000 610	Screw
7	03 0000 180	Float ball

Pos.	Item-No.	Description
8	01 0003 390	Brass lever
9	01 0003 400	Brass pin
10	01 0000 110	Washer
11	04 0000 310	Screw
*	20 0008 495	Repair-kit ST 8