


Spare Parts
Injector ST-62
 Item-No. 20 0062 510



Pos.	Item-No.	Description
1	01 0003 540	Housing ST-62
2	01 0003 550	Nozzle1
3	01 0003 560	Nozzle2
4	20 0060 720	Hose nozzle + check valve
5	05 0000 800	O-ring 6x1,5 EPDM 70 Shore
6	01 0003 585	anchor nut
7	01 0003 595	piston
8	02 0001 312	knob
9	01 0003 575	Coupling nut

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					