


Spare Parts
Unloader ST - 261
Item-No. 20 0261 550



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	20 0260 547	Hand wheel complete	17	04 0001 270	Hex. socket head screw M4x5
2	04 0000 406	Pull rod	18	05 0000 390	Back ring
3	04 0001 490	Cylinder pin	19	05 0001 350	O-Ring 7,65x1,78
4	02 0002 850	Bushing	20	20 0261 529	Section assembly piston
5	01 0004 480	Adjusting nut	21	20 0261 524	Section assembly seat
6	10 0001 700	Adjusting nut	22	01 0004 250	Restrictions part
7	04 0001 630	Hex. socket head screw	23	02 0001 290	Valve cage
8	02 0001 341	Glide ring	24	20 0260 520	Section assembly close road
9	04 0001 610	Hex nut M8x1	25	20 0261 515	Micro switch ST-261
10	04 0001 621	Nut M6	26	20 0261 530	Switch rod complete
11	06 0000 301	Spring	27	05 0000 503	O-Ring
13	04 0000 440	Valve part	28	04 0003 760	Cap nut
14	05 0000 051	O-Ring 5x2,5	29	01 0001 790	Distance bushing
15	06 0000 310	Spring			
16	01 0001 700	protection screw			

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
*	20 0261 513	Mirco switch ST-261 complete	+	20 0261 526	Repair- Kit ST-261