


Spare Parts
Unloader ST - 261
Item-No. 20 0261 551



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	20 0260 547	Hand wheel complete	17	04 0001 270	Hex. socket head screw M4x5
2	04 0000 406	Pull rod	18	05 0000 390	Back ring
3	04 0001 490	Cylinder pin	19	05 0001 350	O-Ring 7,65x1,78
4	02 0002 850	Bushing	20	20 0261 529	Section assembly piston
5	01 0004 480	Adjusting nut	21	20 0261 524	Section assembly seat
6	10 0001 700	Adjusting nut	22	01 0004 250	Restrictions part
7	04 0001 630	Hex. socket head screw	23	02 0001 290	Valve cage
8	02 0001 341	Glide ring	24	20 0260 520	Section assembly close road
9	04 0001 610	Hex nut M8x1	25	20 0261 516	Section assembly switch
10	04 0001 621	Nut M6	26	20 0261 530	Switch rod complete
11	06 0000 301	Spring	27	05 0000 503	O-Ring
13	04 0000 440	Valve part	28	04 0003 760	Cap nut
14	05 0000 051	O-Ring 5x2,5	29	01 0001 790	Distance bushing
15	06 0000 310	Spring			
16	01 0001 700	protection screw			

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
*	20 0261 514	Mirco switch ST-261 complete	+	20 0261 526	Repair- Kit ST-261