


Spare Parts

Unloader ST-291 (Microswitch)

Item-No. 20 0291 550



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	01 0001 695	housing ST-291	17	01 0000 356	locking screw
2	20 0291 465	Seal Seat	18	02 0012 055	handle
3	20 0291 480	check valve	19	02 0012 065	locking screw
4	01 0001 700	protection screw	20	01 0009 105	screw
5	20 0291 470	Piston Rod	21	05 0001 021	O-ring 17 x 1.5
6	02 0012 060	spring adaptor	22	06 0002 085	pressure spring
7	01 0009 030	compensating disk	23	02 0012 105	ball receiver
8	10 0004 460	adjusting ring	24	06 0000 740	steel ball
9	06 0002 065	pressure spring	25	01 0009 120	bush
10	01 0009 025	plate	26	02 0012 075	housing micro switch
11	01 0009 100	spring guide	27	09 0000 270	micro switch
12	04 0001 720	Pressure washer	28	02 0012 080	cap micro switch
13	02 0003 370	Roller holder	29	04 0000 630	Screw
14	06 0000 900	Stainless steel ball	30	01 0000 375	plug
15	01 0009 020	adjusting screw	31	01 0003 295	sealing ring
16	01 0009 115	arresting screw			

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
*	20 0291 495	Repair-Kit Piston Rod	+	20 0291 490	Repair-Kit Check Valve
°	20 0291 485	Repair-Kit Seal Seat			