

## Vorwerk lances and wash brushes

**The original**



Extension pipe with water flow

R+M Nr.	↔	↻	⊗
523 790 1	1000 mm	1/4" M	1/4" F
523 790 2	1500 mm	1/4" M	1/4" F
523 790 3	2000 mm	1/4" M	1/4" F

## Vorwerk wash brushes



A= 300. B= 300 x 100 mm. Nylon

R+M Nr.	C	⊗
523 780	60 mm	1/4" F



A= 240. B= 230 x 80 mm. Hog hair

R+M Nr.	C	⊗
523 70	60 mm	1/4" F
523 75	90 mm	1/4" F

Brush. A= 260. B= 230 x 80 mm.  
Hog hair

R+M Nr.	C
523 72	60 mm
523 73	90 mm

Frame. 260 mm.  
Aluminium

R+M Nr.	⊗
523 76	1/4" F

## Adaptor

Adaptor for lances with coarse thread.  
Coarse thread : 1/4" M

R+M Nr.
010 003 610


## Air injector



1/4" M : 1/4" F. Flow at 100 bar

R+M Nr.	↻	⊗
108 290 60	13 l/min	1.5
108 290 20	34 l/min	2.5

## Brush holder

Suitable for all brushes. Hole spacing 202 mm.  
H x W x D = 90 x 250 x 100 mm

R+M Nr.	(M)
108 290 30	stainless steel

## easywash365+ brush holder



Container with overflow and lateral drain for cleaning. For wall and floor mounting. H x W x D = 670 x 340 x 143 mm

R+M Nr.	(M)
105 810	stainless steel

Symbols ⊗ inlet ↻ outlet ↔ length ↔ flow ⊗ diameter (M) material ℃ temperature