

## Fuel pumps Danfoss

### Pumps with solenoid valve



R+M Nr.	V
826 00	24 V
826 10	230 V

Single line intake or double line intake.  
Pressure adjustable 7 - 15 bar

### Spare parts Danfoss fuel pumps




Cartridge filter

R+M Nr.
825 01




Cartridge filter

R+M Nr.
825 00



R+M Nr.	TYP	coil	hub
825 45	BFP 21 L3	24 V	32 mm
825 40	BFP 21 L3	230 V	32 mm



R+M Nr.	TYP	coil	hub
825 35	BFP 21 R3	24 V	32 mm
825 30	BFP 21 R3	230 V	32 mm

## Accessories fuel pumps

### Check pressure gauges



1/8" M with o-ring sealing. Undamped  $\varnothing$  40 mm.  
Housing plastic.  
Hose connection 500 mm

R+M Nr.	indication
547 105 0	0 - 16 bar

### Cables with connector




R+M Nr.	↔
832 50	500 mm
832 40	1050 mm

## Fuel pumps SP

### Pumps with solenoid valve



Double line intake.  
Pressure adjustable 6 - 14 bar




R+M Nr.	TYP	coil	hub
821 10	46L5316M	24 V	32 mm
821 20	46L5316M	230 V	32 mm

### Pumps without solenoid valve



Double line intake.  
Pressure adjustable 6 - 14 bar



R+M Nr.	TYP	coil	hub
820 20	46L2386	-	32 mm

### Filter complete



R+M Nr.
822 40

### Cartridge filter



R+M Nr.
822 50

### Membrane




R+M Nr.
822 15

### Coil




R+M Nr.	V
821 024	24 V
821 220	230 V



R+M Nr.	TYP	coil	hub
821 30	46L5416 M	24 V	32 mm
821 40	46L5416 M	230 V	32 mm

### Attention!

Rotating direction always stated in view of the shaft.



Symbols TYP type V voltage ↔ length  $\varnothing$  diameter