

Burner equipment & coils

Ignition electrodes














R+M Nr. suitable for 852 10 Kärcher


R+M Nr.	suitable for	
852 12	Kärcher	

















R+M Nr. suitable for 851 30 SIAL


R+M Nr.	suitable for	
850 60	Alto	


















R+M Nr.	suitable for
851 10	LAVORWASH


R+M Nr. suitable for 851 55 Lavor

















R+M Nr.	suitable for
851 65	Idromatic

R+M Nr. suitable for 851 00 PORTO

R+M Nr. suitable for 852 15 MAER

Adjustment of electrodes



- 1 Electrodes have to be positioned close to the atomized spray of fuel without getting in touch with it (ends have to stay dry).
- 2 There has to be sufficient space between the electrodes and the fuel nozzle as well as the flame control to avoid a flash over of the ignition spark.

R+M high quality spare parts are obtained from well-established manufacturers. As a rule they are no original spare parts. The original order numbers and the indication of other information are exclusively for your guidance and furthermore they are not intended for the general use, e.g. invoices addressed to end users. In case of mentioning the original order numbers in your orders it can not be assumed that the products ordered are original spare parts. Original spare parts are supplied when they are especially offered as those in our catalogue or in other mailing pieces such as special offers or newsletters.