


Spare Parts  
Lance "Push and Pull"  
Item-No. 20 0085 910



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	02 0002 770	Cover housing	17	02 0007 500	Hose holder left
2	01 0002 200	Housing	18	04 0002 865	Nut M5
3	07 0007 608	Lance 760 mm	19	02 0002 780	Clamp (1)
4	02 0002 760	Semi casing (2)	20	02 0002 790	Clamp (2)
5	04 0000 051	Screw 3.5x16	21	01 0005 030	Bracket
6	02 0002 750	Semi casing (1)			
7	07 0000 435	Lance 250mm			
8	04 0002 885	Straight pin 4x30			
10	02 0007 530	Shrinkdown plastic tube			
12	04 0002 880	Straight pin 5x20			
13	04 0002 870	Screw M5x16			
14	02 0007 510	Hose holder right			
15	03 0000 280	Aluminium bar			
16	20 0085 300	Hose			

### Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					