


Spare Parts

High Pressure Spray Gun ST-810

Item-No. 20 0810 525



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	10 0000 091	Outlet nut	17	01 0001 245	Pin 4x25
2	02 0000 310	Sealing seat ST-810	18	02 0001 760	Cover ST-810
3	05 0000 040	O-Ring 14,1x1,6	19	04 0000 050	Screw
4	04 0000 330	ball	20	02 0001 810	Lock
5	04 0000 675	Ball holder	21	02 0001 800	Trigger ST-810
6	04 0000 490	Piston rod ST-810	22	02 0001 770	Housing cover ST-810
7	06 0000 560	Pressure spring			
8	01 0000 761	Washer			
9	05 0000 260	O-Ring			
10	05 0000 640	Back ring			
11	01 0000 138	Housing ST-810 1/4" NPT			
12	02 0001 790	Washer, plastic			
13	06 0000 195	Lock ring			
14	02 0001 880	Housing cap			
15	01 0001 260	Pin 4x32			
16	02 0001 755	Plastic housing ST-810			

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
*	20 0810 491	Repair Kit ST-810			