


## Spare Parts

# High Pressure Spray Gun ST-1500 5000psi

Item-No. 20 1500 910



Pos.	Item-No.	Description
1	04 0000 050	Screw
2	01 0001 310	valve housing
3	10 0001 270	Outlet NPT 1/4 fm
4	06 0000 270	Inlet Pipe
5	10 0000 400	Inlet nut
6	04 0000 031	Pin
7	02 0002 050	half shell with bar 5000 psi
8	02 0001 910	half shell
9	20 2000 025	Trigger complete
10	20 2300 380	Piston rod complete
11	20 1500 455	valve screw assembly

## Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
*	20 1500 496	Repair Kit ST-1500 350bar			