


Spare Parts  
**Flowswitch ST-5**  
 Item-No. 20 0005 551



Pos.	Item-No.	Description
1	01 0001 456	Brass housing
2	02 0001 204	Plastik housing
3	20 0005 526	Float with magnet
4	05 0000 116	O-ring
5	10 0001 474	Sealing screw
6	04 0000 730	Nut M4
7	04 0000 725	Screw M4

## Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					