


Spare Parts  
**Coupling ST-45 brass**  
 Item-No. 20 0045 510



Pos.	Item-No.	Description
1	01 0000 017	Bushing coupling
2	06 0000 670	Stainless steel ball
3	05 0000 114	O-Ring 18x2,5
4	05 0000 117	O-Ring 20x2,5
5	01 0000 015	Ferrule coupling
6	06 0000 103	Pressure spring
7	06 0000 101	Snap ring

## Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					