


Spare Parts
Injector ST-160
 Item-No. 20 0160 540



Pos.	Item-No.	Description
1	04 0003 651	injector nozzle 2,1mm
2	04 0003 523	Nozzle
3	04 0003 580	Housing ST-160
4	02 0005 100	cover blue
5	04 0003 558	Screw plug
6	06 0001 100	Spring
7	04 0003 555	Check valve piston
8	05 0000 265	O-ring 2,9x1,78
9	05 0000 301	O-ring 10.82 x 1.78
10	04 0003 550	Hose clip

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					