


Spare Parts

Bypass injector ST-168

Item-No. 20 0168 810



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	04 0003 605	Housing ST-168	14	20 0163 356	Check valve ST-163 G1/4 MK2
2	04 0003 615	Inlet nut ST-168			
3	02 0005 092	Locating disc			
4	04 0003 635	Trigger ST-168			
5	02 0005 093	Protection ring			
6	05 0002 330	O-Ring 27x1,5			
7	05 0002 450	Seal ring			
8	06 0002 090	Pressure spring ST-168			
9	04 0003 649	injector nozzle 1,9mm			
10	04 0003 523	Nozzle 2,3			
11	02 0005 100	Cover blue			
12	20 0161 500	Metering valve ST-161			
13	02 0005 108	Cover grey			

Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
.					